

MATERIALS:

- Looped Vinyl Banner
- (1) Set of X-Poles
- (2) Side Poles
- (2) Black Feet
- (2) Lift Extensions (Optional)

1 STEP ONE

Lay banner on a clean floor, face down. Unfold and assemble the poles that are shock corded together.

2 STEP TWO

Place the X poles in an X shape and place one end in each hole at the banner's corners.

The holes in the banner and holes in the poles should line up.

3 STEP THREE *(if lifted)*

Attach the silver legs to the side poles in banner by using the button feature to lock them in place.

If Lift Extensions were ordered, attach those pieces to each side pole before attaching legs.

4 STEP FOUR

Place each silver leg onto the post of the black feet. The foot should be positioned so that the longer part is towards the back of the display.

For Table Top use, simply detach the legs from the side poles in the banner and slide the feet into the ends of each side pole.

